

INSTALLATION GUIDE FOR HARD GROUND ANCHOR KIT

YOU WILL NEED:

2mm WOOD/METAL DRILL BIT

14mm MASONRY DRILL BIT

14mm SPANNER OR SOCKET SET

HAMMER

MARKER PEN OR PENCIL

PHILLIPS HEAD SCREW DRIVER

HEAVY DUTY MASONRY DRILL

STEP 1

PUT YOUR BENCH ONTO THE PREPARED HARD GROUND/CONCRETE SURFACE AND PLACE THE BRACKETS AT THE BASE OF EACH LEG, WITH THE 2 SMALLER HOLES ON THE WOOD AND THE LARGE SINGLE HOLE ON THE CONCRETE

STEP 2

WITH THE BRACKETS ALL IN PLACE, USING THE 2mm DRILL BIT COUNTERSINK 20mm INTO THE WOOD FOR EACH OF THE 2 HOLES. SCREW IN EACH OF THE WOOD SCREWS UNTIL TIGHT (X8)

STEP 3

NOW MARK THE MIDDLE OF THE 4 X HOLES IN THE BRACKET ON THE CONCRETE WITH THE PEN. LIFT AWAY THE BENCH.

STEP 3

USING THE HEAVY DUTY MASONRY DRILL AND 14mm BIT, DRILL 60MM DEEP ON THE MARKS

STEP 4

PLACE THE BENCH BACK WITH THE BRACKETS SITTING OVER THE HOLES IN THE CONCRETE. PLACE A BOLT IN EACH HOLE AND HAMMER IN. THEN TIGHTEN USING 14 mm SPANNER/SOCKET

